
102
130
131
104
133
110
COMPRESSION ENGINE
135
COMPUTER 120
Light Sensor
FLASH

FIG. 1


200
Define Triggering Sequences
202
Download Triggering Sequences to Camera
204
N
Trigger Condition met
206
Y
Capture image or video
208
Compress image or video
210
Store image or video in data storage device
212
Upload image or video to remote server
214

F. 2


300
Log In
302
Sever lists images/video previously captured and uploaded to Server
304
Select ~~and play or preview~~ an image to view or ~~play~~ video to play
310
Server streams data for selected image or video to viewer
314
Viewer views selected image or video
316
Select next image or video
320
log-out when done
324

F.3


400
Retrieve images/video and camera setting from camera
410
420
Text Annotation entered?
Y
442
store data text
N
443
Verbal annotations entered?
Y
Perform speech to text conversion and store data
444
N
445
Pen annotations entered
Y
Convert handwriting recognition and store text data
448
N
449
Sketches entered on image/video
Y
store bit map data
451
Compress / Encode data
469
Exit

Fig. 4



Fig 5.

Vacuum adapter for viewing inside the chamber


520
522 video camera to see if wafer slide off the arm and block the door
- see if wafer x arm is aligne properly
524 door
526 arm

Fig 6


see if wafer drop off the arm
522
526
520

Fig 7



— see if wafer slide out of cassette

— to see if any wafer missing, cross-slot, double-slot

— to see if the cassette is positioned properly on the support

Fig 8


800
902
810
808
802
804
806
862
840
840
900
910
850
878
821
822
824
826

FIG. 9